



Assembly WITHOUT Expansion Kit:

Attach welded end section to horizontal bars using provided nuts and bolts. Bolts NOT passing through bottom strap require a washer to prevent bolt head from crushing bottom tube. Repeat this step on other end of horizontal tube.

Assembly WITH Expansion Kit:

REMOVE ONE END SECTION AND ATTACH SINGLE UPRIGHTS TO HORIZONTAL AS SHOWN ABOVE. REATTACH END SECTION TO HORIZONTAL ENDS.

