



HOME SAVER.

STOVEPIPE SHIELD INSTALLATION INSTRUCTIONS

The normal clearance for single-wall stovepipe to a combustible material is 18". The Stovepipe Shield allows you to reduce these clearances to 6", per NFPA 211, Section 6-5.1.2, 2000 Edition.

Kit Contains:

- 1 Stovepipe Shield
 - 6 #10 1½" Phillips Screws
 - 6 Ceramic Spacers
-

Tools Needed:

- Drill
 - ⅛" Drill Bit
 - Phillips Screwdriver
 - Tin Snips or Offset Shears
-

Installation Tips:

1. The Stovepipe Shield can be cut to length if desired. If cutting, it will be necessary to drill new holes in the Shield for screws.
 2. If wall protection is being used, make certain that the lower edge of the Shield is at least 4" below the upper edge of the protector.
-

Instructions:

1. Position the Stovepipe Shield on the stovepipe. If using more than one Shield, allow at least 2" of overlap. Mark on the stovepipe where the top center screw hole for the top-most Shield should be drilled. Set Stovepipe Shield aside.
2. Using a ⅛" drill bit, drill the top center hole in the stovepipe first. Insert a screw through the top center hole in the Stovepipe Shield, through a ceramic spacer, and into the hole in the stovepipe. Tighten the screw.
3. Make certain Stovepipe Shield is positioned correctly on the stovepipe, and then drill a second hole in the stovepipe, using a hole in the Stovepipe Shield as a pilot hole. Fasten with a second screw and spacer. Continue drilling holes and fastening screws one at a time.
4. Tighten all screws.



HOME SAVER.

MANTEL SHIELD INSTALLATION INSTRUCTIONS

The normal clearance for single-wall stovepipe to a combustible mantel is 18". The normal clearance from an unlisted stove or insert to a combustible mantel is 36". The Mantel Shield allows you to reduce clearances to 9" for the stovepipe and 18" for the stove or insert, per NFPA 211, Tables 9.5.1.2 and 12.6.2.1, 2003 Edition.

Kit Contains:

- 1 Mantel Shield
- 4 #10 1½" Phillips Screws
- 4 Ceramic Spacers

Tools Needed:

- Drill
- ⅛" Drill Bit
- Phillips Screwdriver
- Tin Snips or Offset Shears

Installation Tips:

1. Make certain that the Mantel Shield extends to the far rear of the mantel so the entire mantel is shielded.
2. To alter the face pitch, carefully bend the Mantel Shield.
3. The Mantel Shield can be cut to length if desired. If cutting, it will be necessary to drill new screw holes in the Shield.

Instructions:

1. Place the Mantel Shield under the mantel making sure the entire mantel is shielded and mark on the mantel where your first screw hole should be drilled.
2. Using a ⅛" drill bit, drill this first hole. Insert a screw through the Mantel Shield and through a ceramic spacer, and into the hole. Tighten the screw.
3. Then use another hole in the Mantel Shield as a pilot to drill a second hole in the mantel. Fasten with a second screw and spacer. Continue drilling holes and fastening screws one at a time.
4. Tighten all screws.

